

EVA-Soft Pad Leather Insoles with neats leather cover



EVA-soft pad blanks with perforated neat's leather cover, inner joint wedge, rubber pad

- the classic one
- very durable
- high wearing comfort
- South German neat's leather, specially tanned
- SG-contaminant-tested

Express service: models 203 wide and 203 FINN

model	bed	cover	sizes
203 women	Sportofit brown 8 mm with 6 mm inner joint wedge (EVA 50 Shore)	Frelen white 3 mm with glued with perforated neat's leather (EVA 25 Shore)	35 - 47/48
203 slim			35 - 47/48
203 wide			19/20 - 47/48
203 FINN			35 - 48
203 extra wide			35 - 47/48
206 (quarter shell)			19/20 - 47/48

design	
The models 203 extra wide und 206 are produced in series with HK-stiffening	

additional design

- HK-stiffening
- · open at front, loose pad
- module cover J1